




WIRELESS PEEPHOLE VIDEO DOORBELL

This smart battery Wifi Video Doorbell lets you answer the door from anywhere, whether you're halfway across the world, It lets you see, hear and speak to visitors with ease using your smart phone or tablet.



Note: If any security apps have been installed in your phone/tablet that could affect the Smart Life/Tuya Smart app, please be sure to grant it the appropriate permissions. please make sure your phone/tablet is connected to your wifi router(only support 2.4g)



USER MANUAL

Please make full charge before use it!




INSTALL APP

NOTE: Search for Smart Life/Tuya Smart on the google play/app stores.

STEP 1

CREATE ACCOUNT

Open the app. Follow the prompts and tap "Sign Up" to create an account. Be sure to allow all permissions requested by the app.



STEP 4


Hold down the button on screen for 5 seconds to initiate wifi configuration mode once you hear the voice prompt, tap "Next" (please make sure the router is within 2 meters)

STEP 4

STEP 2

ADD DEVICE

Tap the (+) to add a new device.



STEP 5

Input your WIFI password for WIFI configuration

TIP:
WI-FI SET UP
NOT WORKING
Try restarting your router.

STEP 3

Tap the QR Code to add a new device
Note: Make sure phone/tablet is connected to wi-fi internet prior to configuring the wi-fi for the machine

STEP 4

Hold down the button on screen for 5 seconds to initiate wifi configuration mode once you hear the voice prompt, tap "Next" (please make sure the router is within 2 meters)

STEP 5

Input your WIFI password for WIFI configuration

TIP:
WI-FI SET UP
NOT WORKING
Try restarting your router.

STEP 3

Tap the QR Code to add a new device.
Note: Make sure your phone/tablet is connected to your wi-fi internet prior to configuring the wi-fi for the machine



STEP 4

Hold down the button of on screen for 5 seconds to initiate wi-fi configuration mode, once you hear the voice prompt, tap the voice prompt, tap "Next," (please make sure the router within 2 meters)



STEP 5

Input your WiFi password for WiFi configuration
TIP: WI-FI SET UP NOT WORKING Try restarting your router.



STEP 6


Put your cellphone in front of the device about 10-20cm to facilitate QR scanning.



STEP 7

APP/DEVICE CONNECT

Once the Wi-Fi set up is complete and you hear the voice prompt confirming that the Wi-Fi configuration was successful, tap "COMPLETE"



DONE!
DEVICE INSTALLATION


Note: Only support the product with button.



FLIP OVER FOR MORE DETAILS!

AUTOMATICALLY WAKES UP

Tap the picture Quick access via app within 3 seconds.




REMOTE VIEWING

NOTIFICATIONS


STANDBY MODE

will receive a push notification. Tap to continue.



MOUNTING WALL INSTALLATION

Support 4 users. The device is added by the QR Code provided (owner of device).



Setup 1:
Put the screws into the device hole

Setup 2:
Take the cable through the door's hole and through the mounting plate, and then tighten the screws

Setup 3:
Plug the cable and buckle into the correct location of LCD machine, and hang to the steel plate.


Kind tips:
1. Do not pull the cable too hard during installation
2. The cable contains data transmission, please do not fold it

TROUBLE SHOOTING


DEVICE WON'T TURN ON AFTER INITIAL USE:
If you remove the device from the mounting plate while the Tamper Alarm function is turned on, you may disable the device. Simply put it back on the mounting plate and press the doorbell button. Go to the app settings to turn off the Tamper Alarm.

DEVICE WON'T TURN ON AFTER INITIAL USE:
If prompted with "The Connection Failed, Please Check The Wi-Fi Configuration is Correct" when ringing the doorbell after the device has been successfully configured, there may be too many barriers (typically walls) between your Wi-Fi router and the device which has weakened the signal.

WONT TURN ON:
Please ensure that the device is properly charged.



PARTS & SPECS



Reminder: All photos here are for reference only. Specifications are subject to the physical product.

Doorbell Installation precautions

1. The product connecting wire is a vulnerable and precise component, and you should check the position of the fixing metal plate during installation when install the screws, prevent the connecting wire from being squeezed and do not forcefully pull the connecting wire.
2. Any operation must be completed in the shutdown state, and the connecting cable contains multiple data transmission, do not compress!
3. Please connect the camera head and the screen in the correct direction, and then install it to your door.


SPECIFICATION:
MATERIAL: Aluminum Alloy
LCD SIZE: 4.3 Inch
DISPLAY RESOLUTION: 3MP
BY PHONE: Android, iOS
MOTION DETECTION: Support PIR
WI-FI MODE: 802.11 b/g/n
INPUT/OUTPUT: Built-in microphone, two-way audio
NIGHT VISIBILITY: with IR Led, Night vision up to 1-3 meters
STORAGE: Cloud storage and TF Card (128G Max.)
BATTERY: 5000mAh battery (charged by USB (5V, 1A))
USER ACCOUNTS: Total 4 Users (Admin user and shared user)
CERTIFICATION: CE, FCC, RoHS



SHARING WITH OTHER PHONES

This device can support 4 users. The shared users can add the device by scanning the shared QR Code provided by the Administrator(owner of device).


Shared users: Please download and install the app before proceeding.



- Step 1:** Choose the device you want to share.
- Step 2:** Click "Setting", choose share device.
- Step 3:** Click "Add Sharing"

TROUBLESHOOTING SHOOTING


WONT TURN ON
Please ensure that the device is properly installed.



- Step 4:** Enter the account you want to share in the account field.
- Step 5:** When the inputs are complete, click "Done" in the upper right corner. Complete sharing!


DEVICE APP FUNCTIONS

After installing the app, go into your device's information by tapping on the added device. Here you may review your pictures, videos, change your Wi-Fi settings, share the device or delete the device.



PLAYBACK

Click "Playback" to check the SD card storage record.
*The device only support above Class 10 FAT32 TF cards.



APP INTERFACE FUNCTIONALITY

- TAP TO TAKE A SHAPSHOT
- TAP AND HOLD DOWN TO TALK
- TAP TO RECORD VIDEO
- BATTERY LIFE
- Quick Settings

PIR SETTINGS

This function can only be enabled AFTER the app has been successfully added to your phone.
When pir alarm(PIR) are turned on, you'll be notified on your phone whenever motion is detected or when theft is attempted.

